



Choctaw Code Talkers 1918

VR Trunk Reference Sheet

Contents:


- 5 headsets
- 5 sets of controllers
- 5 charging cables + charging adapter
- 1 Lesson Guide
- 1 bag of lens cleaners
- 1 bag of gasket cleaners (anti-bacterial wipes)
- 1 VR Trunk reference sheet
- 1 trunk contents photo


Reminders:

- Please note your return date carefully. Your borrowing period begins on the Wednesday of pick-up and ends the Tuesday of drop-off.
- Upon return and inventory of the trunk and its contents, the charge on your credit card (\$250) will be refunded.
- If the trunk is returned more than 72 hours after the agreed-upon date, the charge (\$250) will become permanent on the provided credit card.
- Headsets should be cleaned and charged before the trunk is returned. Instructions for headset care are included below.

Choctaw Code Talkers 1918 VR Instructions

PREPARE FOR LESSON

- Ensure access to all necessary content:
 - Handouts (digital or printed)
 - Readings (digital)
- Setup VR Headsets
 - Prepare a different space for each headset. This includes:
 - Seat w/ table/desk
 - Enough space for users to move without obstruction
- Power VR Headsets
 - Loop the controller straps around your wrists
 - Power on headset (left side, near strap connection)
 - Hold the controllers in your hands
 - Once the headset starts, you'll see a home screen
- Launch Experience
 - Select the Choctaw Code Talkers 1918 app by pressing the  icon (use A button or trigger)



OR



- Accept “boundary” pop-up:
- Select “return to boundary,” then “create new boundary,” and “confirm”
- Adjust volume (button on the right side, bottom of the headset)
- Place controllers down, remove headset, and position it 3 feet away from seat to pause the experience

For subsequent users: The headset pauses at and will resume from where the last person left off/placed down. *Ask your students to remove headsets during credits and set them outside the boundary.* The experience automatically restarts after the credits.

Restarting Experience (if needed): Press the Oculus button on the right-hand controller. From the home screen, relaunch the app.



- Lesson Tips
 - Use headsets as one station of your learning activities on WWI Choctaw Code Talkers (other lesson activity options supplied in trunk).
 - Each VR experience lasts approximately 5 minutes.
 - Remind students removing headsets will stop and restart experience – they will need to rewatch completely if taken off mid-experience.

- Powering Off and Ready for Return
 - Power Off/Charge
 - Place headset on and hold the power button (left side) to power off the headset.
 - When prompted, select power off on the screen. Take off headset.
 - Ensure it's off by briefly putting it back on—if the screen remains dark, it's off.
 - Charge headsets with the provided adapter and cables. A green light (top of headset) indicates full charge.

- Clean headsets
 - DO NOT use anything on the lenses of the headsets unless necessary
 - If a lens must be cleaned, only use the soft electronic wipes included in the labeled bag.
 - Use anti-bacterial wipes included in the trunk to clean the headset gaskets (portion of the headset that touches the face when worn) before putting the headsets away.

- **Storing Headsets:**
 - Place headsets back in the trunk following the reference photo for proper storage.
 - Ensure all headsets and items listed in the contents are returned.

- **Trunk Return:**
 - Return the trunk to the Museum and Memorial on the agreed-upon date.

VR Headset Troubleshooting:



Choctaw Code Talkers Meta Quest 3s Troubleshooting

- No image in the headset
 - o Check that the headset is powered on, the light on the front of the headset should be lit.




- o If the light is lit, but there is no image, press and hold the power button to force power off. The headset will make a noise to indicate when it's turning off. Power back on.
- No Sound
 - o Check that the volume is set at the right level, the volume can be adjusted with the buttons on the bottom right of the headset.
 - o If the volume is up and there is no sound, press and hold the power button to bring up the menu to restart.





- Controller not working/Controller disconnected
 - o Make sure you're using the correct color-coded controller with the headset
 - o Wear the headset and click the buttons a few times to see if it will wake the controller
 - o Force power off the headset with the power button by pressing and holding, power on the headset and check if the controllers work.
 - o Replace the batteries in the controllers. (see next page for images)



- Someone presses the button on the bottom of the headset



- This will send the user to a screen that asks them to create a boundary again – have them follow the same directions for boundary creation in setup
- Afterwards, select “continue in passthrough”